

10.5 COLOUR CHANGE VALVE CIRCULATION, FWV400-Z

Item	K	Qty	Part No.	Description
1		1	384194	Colour valve Circulation HM 2.6 mm/ 5 bar/ 400 bar
2	◆ ★	2	350485	Sealing screw
3	◆ ★	2	350486	Sealing collar
4	★	2	350487	Pressure part
5		2	350490	Tension nut AL
6	★	2	350491	Pressure ring
7	◆ ★	2	384120	Valve rod assy.assembled
8		1	**	Valve housing Circulation preassembled
9		2	384345	Piston
10		2	9913014	Hexagon nut
11	◆ ★	12	9923513	Spring plate
12	◆ ★	2	9974065	O-ring
13	◆ ★	2	9974187	O-ring
14		2	350482	Pressure spring 400 bar; 40 MPa; 5800 psi
15		1	9992511	Loctite 243
16		2	384323	Plug
17		2	104376	Lock screw
18		1	9992831	Loctite 542
19		1	9998808	Grease Beacon EP2
		1	384912	Service-Set

★ = Included in service set
 ◆ = Wearing part

**
 The valve housing can not be ordered as a spare part, but only the whole colour change valve.

